

**Retainer Set Includes:**

- 2 Socket head cap screws.
- 2 Vented and tapped dowels

The Fastest, Least Expensive Way to Mount Shaped and Form-Pointed Punches.

A standard K2 key flat orients the shape inside the retainer.

Just place two round dowel holes in your die shoe, and you are ready to locate complex shaped punches.

Dowels are finished, and dowel holes are slip-fit sized. Retainer is ready for CNC mounting.

Product Code	D	W	L	B	S	A	C	E	X	Y	F
PRSF10	10	41.0	43.5	5.0	34.0	26.924	19.05	11.12	7.5	9.0	M8
PRSF13	13	48.5	49.6	6.5	37.0	29.972	19.05	14.27	6.5	12.0	M8
PRSF16	16	51.7	52.7	8.0	38.6	31.750	19.05	15.87	6.0	13.5	M8
PRSF20	20	56.8	59.3	10.0	41.9	33.528	19.05	17.47	5.0	16.5	M10
PRSF25	25	64.5	68.9	12.5	46.7	40.640	23.82	19.84	7.0	22.0	M12
PRSF32	32	64.5	68.9	16.0	46.7	40.640	23.82	19.84	7.0	22.0	M12